


DA-JB4150 INSTALLATION MANUAL





This manual is intended for users of the DA-JB4150 junction box. It includes instructions for mounting the DA-JB4150 junction box to a wall.

- **This junction box is intended to be used with some models of cameras. Do not use it with other models of cameras.**
- **This installation should be performed by a qualified service personnel in conformance to all local codes.**
- **You may need to reinforce the wall. If the wall is not strong enough to support the camera, the camera may fall.**
- **Do not use this product for other purposes.**

Mounting



Mount the junction box to the wall and connect your camera as follows:



If it is necessary to waterproof, seal the part shown in lines.

1 Mount the junction box to the wall by using the screws and the anchors.

- Use the provided guide pattern to check the distance between the screw holes if necessary.



If it is necessary to waterproof, seal the part in lines of the camera before screwing the camera to the bushing

Check the type of the bushing on each model



TC-T5531WRX, TC-T5531WRXP
TC-T4222WRX, TC-T4221WRXP
TC-E4211WRX



DC-E4213WRX, DC-E4216WRX
DC-E4513WRX, DC-T4533HRX
DC-T4236HRX, DC-T4233HRX
DC-T4236WRX, DC-T4233WRX

- 2 Insert the bushing to the junction box. Match the cable hole of the product, the projection of the silicon bushing, and the PT 3/4" cap.
- 3 Insert cables from external devices, network and power adapter to the junction box like a round wound.

4 Screw the camera to the bushing.

Before fixing the product, make sure to seal the inside of the bracket and the hole to the wall with silicone seal.

Dimensions

Unit: mm (inch)

